



REMARQUES

- Ne pas exposer l'appareil à la pluie ou à l'humidité.
- Débranchez l'appareil avant d'ouvrir le boîtier
- Toutes les personnes impliquées dans l'installation, le fonctionnement ou la réparation de l'appareil doivent être qualifiées. Nous vous recommandons de bien suivre les instructions dans le manuel d'utilisation.

INSTRUCTIONS DE SECURITE

A NOTER :

- Nous vous recommandons d'être toujours prudents lors de l'utilisation de l'appareil.
- Assurez-vous que la tension est correcte afin de ne pas risquer un choc électrique. Ne jamais toucher les fils !
- L'appareil a quitté l'entrepôt dans de parfaites conditions. Afin de préserver la durée de vie de l'appareil et de vous assurer une utilisation optimale, nous vous conseillons de bien suivre les recommandations dans ce manuel.
- Les dommages causés par une mauvaise utilisation ne sont pas pris en garantie.
- Toujours maintenir l'appareil éloigné des sources de chaleur.
- Si l'appareil a été exposé à d'importantes fluctuations de températures (pendant le transport), ne pas allumer l'appareil immédiatement. La condensation peut endommager l'appareil. Laissez l'appareil éteint le temps que sa température atteigne la température ambiante.
- Si le câble d'alimentation est endommagé, veuillez le remplacer par un cordon de même type. Veuillez contacter votre revendeur.
- L'écran ou les lentilles doivent être changés si ces éléments sont endommagés (rayures, fissures...etc.) et risquent de modifier le bon fonctionnement de l'appareil.
- Nous vous recommandons de toujours débrancher l'appareil quand celui-ci ne fonctionne pas ou avant de faire tout entretien ou nettoyage.
- Maintenez l'appareil éloigné des enfants ou des personnes non qualifiées.
- Il n'y a pas de pièces détachées dans l'appareil. L'entretien et les réparations de l'appareil doivent être entrepris par des personnes qualifiées.

MODE MUSICAL

Le show lumineux se déclenche au son de la musique. Le moteur tourne dans le sens des aiguilles d'une montre et inversement. Si le mode musical n'est pas activé au bout de 10 secondes, l'appareil reste en position statique : l'intensité des LED s'affaiblit et le moteur s'arrête

MODE MANUEL

Vous pouvez régler la sensibilité au son grâce au potentiomètre situé à l'arrière de l'appareil. Plus le potentiomètre est réglé sur la position élevée, plus la sensibilité au son est forte. En position basse, la sensibilité au son est faible. Si le potentiomètre est au plus bas, le mode musical est désactivé : l'intensité des LED s'affaiblit et le moteur s'arrête

CARACTERISTIQUES TECHNIQUES

Moteur : DC12V 35R/MIN par 1 pc

Alimentation : AC100-240V / 47-63HZ

LED : RGB / 3 en 1 / 3W par 2 pcs

Consommation : 25W max.

Fusible : 1A/250V

Poids : 4.1 kg

Dimensions (L x l x h) : 311.5 x 270 x 264





XLIGHT 340 LED

USER MANUAL

CAUTIONS

Keep this device away from rain and moisture! Unplug mains lead before opening the housing!

Every person involved with the installation, operation and maintenance of this device has to: -Be qualified -Follow the instructions of this manual

SAFETY INSTRUCTIONS

CAUTION! Be careful with your operations. With a dangerous voltage you can suffer a dangerous when touching the wires! This device has left our premises in absolutely perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual.

IMPORTANT

- Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems.
- Keep away from heaters and other heating sources!
- If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your device. Leave the device switched off until it has reached room temperature.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Shields, lenses or ultraviolet screens shall be changed if they have become visibly damaged to such an extent that their effectiveness is impaired, for example by cracks or deep scratches.
- Always disconnect from the mains, when the device is not in user or before cleaning it.
- Please note that damages caused by manual modifications on the device or unauthorized operation by unqualified persons are not subject to warranty.
- Keep away children and amateurs from the device!
- There are no serviceable parts inside the device. Maintenance and service operations are only to be carried out by authorized dealers.

MUSIC ACTIVE

LED color random show and mix-color are triggered by low bass. The motor will spin with clockwise direction, counter-clockwise direction and static state. If the unit is not triggered by music within ten seconds, it will exit automatically and enter wait state (LED is lightless and the motor stops to spin).

MANUAL MODE

The highest the manual potentiometer, the more sensitive music active.

If the potentiometer is adjusted the lowest, the music function is shut down and exit after ten seconds (LED is lightless and the motor stops to spin).

SPECIFICATIONS

Motor : DC12V 35R/MIN*1PCS

Power input: AC100-240V / 47-63HZ LED

System : RGB/3IN1/3W*2pcs

Power draw : 25W max.

Fuse : 1A/250V

Weight : 4.1 Kg

Dimension : L264*Ø311mm

