

70
50
15
5
0
mm

1 Scope of delivery

Gray AWG#22-23
White AWG#24-26

2

min. 25mm
Stripping length

Fold braid shield backwards

Wrap braid shield evenly around cable jacket

3 **T568B**

Gray AWG#22-23
White AWG#24-26

Untwist pairs and insert them into wire manager

4

Step 1

Step 2

5

Cut wires
Step 1

Step 2

6 **T568B**

Keep foil for better performance

7

8

9

Click

10

Place the metal cover onto the plug

11

Slide cable boot forward until snap-in (1)

1 ← 2
Tighten cable gland until stop (2)

12