	Symbols			\in	9									0								(4)			*		\odot	•			
Model		PH000	PH00	PH0	PH1	2.0	2.5	3.0	4.0	T4	T5	T6	T8	T10	T15	T20	P2	P5	P6	H0.7	H1.5	H2.0	H3.0	TA2.0	TRI00	TRIO	TRII	PZ0	PZ1	Spanner 2.6	Pin
Apple	Mac Pro & Air	•	•	•	•						•	•	•					•													
	Mac Book Series	•	•							•		•	•	•					•			•				•	•				
	iPad Series	•								•																					
	iPod Series	•	•																												
	iPhone5 & Series	•	•			•											•														•
Celler Phone	нтс	•				•				•	•	•					Т														
	ASUS	•				•				•	•	•					Т														
	SONY	•									•		•																		
	SHARP	•															Т														
	Motorola	•				•				•	•	•	•				Г														
	NoKia	•				•				•	•	•					\vdash														
	Samsung	•	•			•						•					\vdash														
	LG	•				•						•					\vdash														
Video	Microsoft X box serias			•	•			•		•	•	•	•		•	•															
eo Game	Nintendo series	•		•	•												Г			•					•	•	•				
	Sony series	•		•	•									•											•	•	•				
	Sega series			•	•																										
Toy	Toys , model		•	•	•	•	•	•	•	•	•	•	•	•	•	•					•		•	•							
Case, controller or other accessories or video games		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					•		•		•	•	•	•	•	•	
Security equipment of electronic products																								•						•	