




Charging instructions



1. Connect GP PowerBank directly to a power source. Never use extension cords.
2. Charge only GP NiMH batteries in GP PowerBank in pair(s). Both AA and AAA size batteries can be charged at the same time.



3. Insert GP NiMH batteries into GP PowerBank according to the battery polarity. Avoid reverse charging.
4. Do not charge same size batteries of different capacities at the same time.
5. The green LED indicators will remain on during charging. Only when the charger is unplugged or the batteries are removed, the indicators will switch off.
6. Charging Time

Battery	2100 series	1800mAh	1600mAh	1300mAh	800mAh	750mAh	700mAh
Size	AA	AA	AA	AA	AAA	AAA	AAA
Hour	34	25	22	16	25	23	22

* For brand new batteries, 2 to 3 times of charging and usage cycles are required to optimize the batteries' performance.

* If batteries are stored for more than one week, always recharge them before use.

Safety Instructions

Important

1. GP PowerBank is designed for indoor use only. Do not expose it to rain or snow.
2. Charge only NiMH type rechargeable batteries. Other types of batteries may burst causing personal injury and damage.
3. Do not mix different types of batteries (eg. NiMH, NiCd, alkaline, etc) in the electrical device.
4. Remove batteries from the electrical device if the device is not going to be used for a long time.
5. Do not incinerate, disassemble or short circuit batteries.
6. If the performance of the batteries decrease substantially, it is time to replace the batteries.

	UL Plug	BS Plug	GS Plug
Input voltage	120V AC	230V AC	230V AC
Output voltage	2.8V x 2	2.8V x 2	2.8V x 2
Charging current AA AAA	100mA 45mA	100mA 45mA	100mA 45mA
Charging temperature	0°C to 45°C	0°C to 45°C	0°C to 45°C
Battery storage temperature	-20°C to 35°C	-20°C to 35°C	-20°C to 35°C